

BUFFALO TURBINE LLC

180 Zoar Road
Springville, NY 14141
TEL: 716 592 2700 FAX: 716 592 2460
EMAIL : info@buffaloturbine.com
www.buffaloturbine.com



BUFFALO TURBINE'S MODEL BT-CSM2G SPRAYER / GRANULAR OPERATOR'S MANUAL AND PARTS BOOK

02/25-BT MAN

BUFFALO TURBINE SPRAYERS MODEL CSM2

WARRANTY REGISTRATION FORM & INSPECTION REPORT

WARRANTY REGISTRATION

This form must be filled out by the dealer and signed by both the dealer and the customer at the time of delivery

Customer's Name	_____	Dealer Name	_____
Address	_____	Address	_____
City, State, Code	_____	City, State, Code	_____
Telephone Number	_() _____		
Email Address	_____		
Sprayer Model	_____	Circle one:	
Serial Number	_____	Commercial Use	
Delivery Date	_____	Private Use	

DEALER INSPECTION REPORT

_____ Tire Pressure Check – Trailer Model
_____ Wheel Bolts
_____ Belt Tension
_____ Lubricate Machine
_____ Fasteners Tight

SAFETY CHECKS

_____ All Decals Installed
_____ Review Operating and
Safety Instructions
_____ Guards in Place and secure

I have thoroughly instructed the buyer on the above described equipment which review the included Operator's Manual content, equipment care, adjustments, safe operation and applicable warranty policy.

Date _____ Dealer's Rep. Signature _____

The above equipment and Operator's Manual has been received by me and I have been thoroughly instructed as to the care, adjustments, safe operation and applicable warranty policy.

Date _____ Owner's Signature _____


FAX A COPY OF THIS FORM TO BUFFALO TURBINE AT 716 592 2460

SERIAL NUMBER LOCATION

Always give your dealer the serial number of your Sprayer and/or optional Duster when ordering parts or requesting service or other information.

The serial number plate(s) is located where indicated in the picture below. Please document the number in the space provided for easy reference.

Model CSM2 Sprayer



Serial number location (sitting in the operator's seat)
(right front side of frame below the muffler)

Serial Number _____

BUFFALO TURBINE

DEBRIS BLOWERS

WARRANTY

Buffalo Turbine LLC warrants the **Model CSM2G** to be free from defects in material and workmanship, under normal use and service. Obligation under this warranty shall extend for a period of 1 year (12 months) and shall be limited to, at the option of Buffalo Turbine, replacement of any parts found, upon inspection by Buffalo Turbine, to be defective.

WARRANTY CLAIMS

The purchaser claiming under this warranty shall submit a warranty claim in the prescribed form to Buffalo Turbine or an Authorized Dealer, for inspection by an authorized company representative.

LIMITATIONS OF LIABILITY

This warranty is expressly in lieu of all other warranties expressed or implied and all other obligations or liabilities on our part of any kind or character, including liabilities for alleged representations or negligence. We neither assume nor authorize any other person to assume on our behalf, any liability in connection with the subsequent sale of the **Model CSM2G**.

This warranty shall not apply to any Sprayer or optional Duster, which has been altered outside the factory in any way so as, in the judgement of Buffalo Turbine, to affect its operation or reliability, or which has been subject to misuse, neglect, or accident.

This warranty does not cover parts and accessories, which are under separate guarantee form the manufacturers and service can be, obtained form their service facilities. No warranty is extended to regular service items such as lubricants, belts, paint and the like.

OPERATION MANUAL

The Purchaser acknowledges having received training in the safe operation of the Sprayer or optional Duster and further acknowledges that Buffalo Turbine does not assume any liability resulting from the operation of the Sprayer/Duster in any manner other than described in the Operator's Manual supplied at the time of purchase.

WARRANTY VOID IF NOT RESGISTERED


1 INTRODUCTION

Congratulations on your choice of a Buffalo Turbine Sprayer and/or Duster. This equipment has been designed and manufactured to meet the needs of the Insect Control Industry.

Safe, efficient and trouble-free operation of your Buffalo Turbine Unit requires that you and anyone else who will be operating or maintaining this unit, read and understand all of the safety, operation, maintenance and trouble shooting information contained within this Operator's manual.

This Manual covers the Model CSM2G.

Keep this manual handy for frequent reference and to pass on to new operators or owners. Call your Buffalo Turbine dealer or distributor if you need assistance, information, or additional copies of the manuals.



Top View of the Model CSM2


OPERATOR ORIENTATION – The directions left, right, front and rear, as mentioned throughout the manual, are as seen from the driver's seat and facing in the direction of travel.

2 SAFETY

SAFETY ALERT SYMBOL

This safety Alert symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**

The Safety Alert symbol identifies important safety messages on the Buffalo Turbine Sprayer or Duster and in the manual. When you see this symbol, be alert to the possibility of personal injury or death. Follow the instructions in the safety message.



Why is SAFETY important to you?

3 Big Reasons:

- Accidents Disable and Kill**
- Accidents Cost**
- Accidents Can Be Avoided**

SIGNAL WORDS: Note the use of the signal words **DANGER**, **WARNING** and **CAUTION** with the safety messages. The appropriate signal word for each message has been selected using the following guidelines:

1. **DANGER** – An immediate and specific hazard which **WILL** result in severe personal injury or death if the proper precautions are not taken.
2. **WARNING**- A specific hazard or unsafe practice which **COULD** result in severe personal injury or death if proper precautions are not taken.
3. **CAUTION** – Unsafe practices which **COULD** result in personal injury if proper practices are not taken, or as a reminder of good safety.

SAFETY

YOU are responsible for the **SAFE** operation and maintenance of your Buffalo Turbine Sprayer or Duster. **YOU** must ensure that you and anyone else who is going to operate, maintain or work around the Buffalo Turbine unit be familiar with the operating and maintenance procedures and related **SAFETY** information contained in this manual. This manual will take you step-by-step through your working day and alerts you to all good safety practice while operating this unit.

Remember **YOU** are the key to safety. Good safety practices not only protect you but also the people around you. Make these practices a working part of your safety program. Be certain that **EVERYONE** operating this machine is familiar with the procedures recommended and follows safety precautions. Remember most accidents can be prevented. Do not risk injury or death by ignoring good safety practices.

- Sprayer/Duster owners must give operating instructions to operators or employees before allowing them to operate this unit, and at least annually thereafter per OSHA (Occupational Safety and Health Administration) regulation 1928.57.
- The most important safety device on this equipment is a **SAFE** operator. It is the operator's responsibility to read and understand ALL Safety and Operating instructions in the manual and to follow these. All accidents can be avoided.
- A person who has not read and understood all operating and after instructions is not qualified to operate the machine. An untrained operator exposes themselves and bystanders to possible serious injury or death.
- Do not modify the equipment in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment.
- Think **SAFETY!** Work **SAFETY!**

2.1 GENERAL SAFETY

1. Read and understand the Operator's Manual and all safety signs and safety labels before operating, maintaining, and adjusting.
2. Provide a first-aid kit for use in case of an accident. Store in a highly visible place.
3. Provide a fire extinguisher for use in case of an accident. Store in a highly visible place.
4. Wear appropriate protective gear. This list includes but is not limited to:
 - A hard hat
 - Protective shoes with slip resistant soles
 - Protective glasses or goggles
 - Heavy gloves
 - Wet weather gear
 - Hearing protection
 - Proper Breathing Apparatus (during chemical spraying and dusting)
5. Do not operate without shields and guards in place.
6. Do not allow riders.
7. **Wear appropriate ear protection for prolonged exposure to excessive noise.**
8. Stop engine, set park brake, remove ignition key and wait for all moving parts to stop before attempting to service or adjust.
9. Clear the area of people, especially small children, before starting the unit.
10. Review all safety related items annually with all personnel who will be operating or maintaining this Buffalo Turbine unit.

2.2 OPERATING SAFETY

1. Read and understand the Operator's Manual and all safety signs before operating, servicing or adjusting.
2. Do not allow riders.
3. Install and secure all guards and shields before starting or operating.
4. Keep hands, feet, hair and clothing away from moving parts.
5. Set the Unit on level ground, stop engine, set park brake, remove ignition key and wait for all moving parts to stop before attempting to service, repair or adjust.
 - a) Before servicing or repairing the Models CS and CSM2, **Turn Off Engine and Disconnect Battery Terminals !**
6. Clear the area of all bystanders, especially children, before starting.
7. Wear appropriate hearing protection when operating the machine.
8. Do not allow people, pets or other animals to come within 200 feet of the outlet air stream.
9. Wear eye and ear protection.

2.3 MAINTENANCE SAFETY

1. Follow ALL operating, maintenance and safety information in the manual.
2. Support the machine with blocks or safety stands when changing tires or working beneath it.
3. Do not adjust any of the belts when the unit is running and engaged.
4. Make sure all guards are in place and properly secured when operating or maintaining the Sprayer.
5. Never wear ill-fitting, baggy or frayed clothing when working around or on any of the drive system components.

2.4 TRANSPORT SAFETY

1. Make sure you comply with all local regulations regarding transporting equipment on public roads and highways.
2. Ensure that the **SMV** (Slow Moving EMBLEM) and all reflectors and lights required by the local highway and transport authorities are in place and are clean and visible by overtaking and oncoming traffic.
3. **Do not allow any riders! (except when seat is provided)**
4. The rectangular tubing at the base of the sprayer unit must be used to load and unload the Sprayer unit onto a vehicle. Use caution when directing the lift forks into the rectangular tubing due to the 50 gallon stainless steel tank location. DO NOT OVERLOAD LIFT TRUCK.

2.5 STORAGE SAFETY

1. Store the Sprayer (or optional duster) on a firm, level surface.
2. Store away from areas of human activity. Do not permit children to play on or around the stored machine.
3. Make sure the unit is sitting, or blocked up firm and solid and will not tip or sink into a soft area.
4. Cover with a weatherproof tarpaulin and tie down securely.

2.6 TIRE SAFETY (Trailer Models)

1. Failure to follow proper procedures when mounting a tire on a wheel or rim can produce an explosion, which may result in serious injury or death.
2. Do not attempt to mount a tire unless you have the proper equipment and experience to do the job.
3. Have a qualified tire dealer or repair service perform required tire maintenance.

2.7 SAFETY DECALS

Keep safety decals and signs clean and legible at all times.

1. Replace safety decals and signs that are missing or have become illegible.
2. Replaced parts that displayed a safety sign should also display the current sign.
3. Safety decals or signs are available from your Dealer Parts Department.

How to Install Safety Decals:

- Be sure that the installation area is clean and dry.
- Decide on the exact position before you remove the backing paper.
- Remove the smallest portion of the split backing paper.
- Align the decal over the specified area and carefully press the small portion with the exposed sticky backing in place.
- Slowly peel back the remaining paper and carefully smooth the remaining portion of the decal in place.
- Small air pockets can be pierced with a pin and smoothed out using the piece of decal backing paper.

2.8 SIGN-OFF FORM

Buffalo Turbine recommends that anyone who will be operating and/or maintaining the Buffalo Turbine Sprayers or Dusters must read and clearly understand ALL Safety, Operating and Maintenance information presented in this manual.

Do not operate or allow anyone else to operate this equipment until such information has been reviewed.
Annually review this information before the season start-up

Make these periodic reviews of SAFETY and OPERATION a standard practice for all of your equipment. We feel that an untrained operator is unqualified to operate this machine.

A sign-off sheet is provided for your record keeping to show that all personnel who will be working with the equipment have read and understand the information in the Operator's Manual and have been instructed in the operation of the equipment.

SIGN-OFF FORM

[illegible]

3. SAFETY DECAL LOCATIONS

The types of decal's on the blower units are shown below. For locations of each label, see parts reference in back of this manual.

Good safety requires that you familiarize yourself with the various Safety Decal's, the type of warning and the area, or particular function related to that area that requires your **SAFETY AWARENESS**.

• **Think SAFETY! Work SAFETY!**

! ATTENTION !

1. KEEP HANDS, FEET AND CLOTHING AWAY FROM POWER DRIVEN PARTS.
2. STOP ENGINE BEFORE LEAVING OPERATOR'S POSITION.
3. MACHINE HAS TO BE COMPLETELY STOPPED BEFORE STARTING TO ADJUST OR LUBRICATE.
4. KEEP PEOPLE AND PETS AT SAFE DISTANCE FROM MACHINE.
5. KEEP ALL GUARDS AND SHIELDS IN PLACE.



NOTE: All decals are at 50% of actual size

REMEMBER - If Safety Decal's have been damaged, removed, become illegible or parts replaced without decal's, new decal's must be applied. New decal's are available from your authorized dealer.

4. OPERATIONS

OPERATING SAFETY

1. Review the Operator's manual before operating.
2. Keep all guards and shields in place.
3. Do not allow riders.
4. Clear the area of people, pets and other animals before starting.
5. Ensure that lights and reflectors are clean and working and comply with the regulations of transport authorities.
6. Review safety instructions with all operators annually.

4.1 TO THE NEW OPERATOR OR OWNER

Buffalo Turbine Sprayers and optional dusters are designed to quickly and efficiently apply concentrated sprays and/or dust, giving a thorough and wide-ranged coverage never before possible. Being adjustable allows a desired degree of agitation to the foliage, with enough velocity to completely carry through the tops of trees as well as through row after row of heavy thick leaf cover in row crops.

Many of the features incorporated into the machine are the result of suggestions made by customers like you. Read the manual carefully to learn to operate the machine safely and how to set it to provide maximum efficiency. The manual will take you step-by-step through your working day. By following the operating instructions in conjunction with a good maintenance program, your Buffalo Turbine Unit will provide many years of trouble-free service.

4.2 BREAK-IN

Although there are no operational restrictions on the Sprayer or optional Duster when it is used for the first time, it is recommended that the following mechanical items be checked:

- A. Operating for first ½ hour
 1. Retorque all wheel bolts and axle nuts. (Trailer Models)
 2. Re-torque all other fasteners and hardware.
- B. Operating for first 5 hours
 1. Retorque all hardware and fasteners.
 2. Check the drive belt tension. Adjust as required.
 3. Go to the normal servicing and maintenance schedule as defined in the Maintenance Section.

4.3 PRE-OPERATION CHECKLIST

Efficient and safe operation of the Buffalo Turbine Sprayers and Dusters require that each operator reads and understands the operating procedures and all related safety precautions outlined in this section. A pre-operation checklist is provided for the operator. It is important for both personal safety and maintaining the good mechanical condition of the machine that this checklist is followed.

Model CSM2

Before operating the Sprayer and each time thereafter, the following areas should be checked off:

1. Lubricate the machine per the schedule outlined in the maintenance section.
2. Prime the Hypro pump especially when the liquid tank was drained and cleaned.
3. Use an appropriate vehicle designed to handle this type of equipment.
4. Ensure that the machine is properly attached and anchored to the vehicle.
5. Make sure all guards and shields are in place, secured and functioning as designed.
6. Check the belts and pulleys for proper tension and alignment.
7. Ensure all bearings turn freely.

4.4 REPAIR PARTS

Use Buffalo Turbine repair parts only to ensure safe and efficient operation of the sprayers and dusters. Warranty will be void if substitute replacement parts are used.

MODELS CSM2

Before Operating the Sprayer (optional duster) and each time thereafter, the following areas should be checked off.

1. For fuel, oil, and operating information of the Kohler Engine, refer to the manufacturers specs included with this manual.
2. The trailer models must have proper tires, warning signs and lights when on public highways and roads. Check your local Motor Vehicle Dept. or law enforcement for restrictions. **Maximum speed is 45mph!**
3. Insure the Trailer Unit and Towing Vehicle have the proper receiver and coupler.
4. Make sure all guards and shields are in place, secured and functioning as designed.
5. Always use eye and hearing safety protection when operating this or any other equipment.

4.6 FIELD OPERATION

OPERATION SAFETY

1. Review the Operator's manual before starting.
2. Do not allow riders unless seat is provided.
3. Keep all guards in place when operating equipment.
4. Stop engine, set park brake, remove ignition key and wait for all moving parts to stop before dismounting to service, adjust or repair.
5. Do not direct air stream towards people, pets or other animals or in congested areas.

4.7 Operating RPM (Both Models)

The Models CSM2 may be run at maximum RPM or wide-open throttle. This recommendation is made to insure maximum coverage necessary. The Sprayer (optional duster) can operate at a slower RPM if shorter distance or less coverage is required.

When operating the machine, follow these procedures:

1. Start and operate the Sprayer/Duster according to owner's manual.
2. Make sure Sprayer (optional duster) accessories are disengaged before starting.
3. Clear the area of bystanders before starting.
4. Model CSM2 are equipped with an electric remote nozzle, liquid, dust bin and throttle cab control box: (12v system)
 - a. Pressing the toggle switch marked "NOZZLE" on the hand held cab control box changes the air stream direction. The nozzle will stop turning by releasing the toggle switch (momentary switch). Use caution and always check clearances around nozzle rotation. (360-degree rotation).
 - b. The toggle switch marked "LIQUID" turns the pump on and off. Flow rate has to be adjusted at the pressure relief valve. Have the nozzle in position before turning pump on. The nozzle tips have a .036 orifice opening (6502). A variety of sizes are available.
 - c. The momentary toggle switch marked "THROTTLE" will raise and lower the RPM of the Kohler engine. Pressing or releasing the toggle switch in either direction will either raise or lower the engine's RPM. Adjustment is from an idle to maximum RPM.
 - d. OPTION: The momentary toggle switch marked "DUST BIN GATE" will open and close the dust feed gates and will adjust for variable feed rates of chemical dust into the air stream.
 - e. OPTION: The toggle switch marked "DUST BIN" will engage the clutch of the dustbin. The dust feed shafts and the dust agitators will be turning when the toggle switch is in the on position.



ALL LIQUID AND DRY CHEMICAL MIXTURES HAVE SPECIFIC COVERAGE RATINGS. GROUND TRAVEL SPEED, ENGINE RPM OF THE MODEL CS II, WIND SPEED AND ACREAGE TO BE COVERED, HAS TO BE CALCULATED AND MANUALLY MEASURED FOR PROPER COVERAGE. Dustbin opening and / or nozzle tip orifice size will greatly affect coverage.

NOTE: Make sure the remote cable is clear of all moving parts.

corners of the frame ONLY.

4.8 TRANSPORTING (trailer pkg.)



TRANSPORT SAFETY

1. Clean lights, reflectors and SMV before transporting on a public road or highway.
2. Insure that unit complies with all regulations by the local transport authorities for lights and reflectors and SAFETY equipment.
3. Do not allow riders on roads or highways, even if seat is provided.
4. Travel at a safe speed. Slow down for corners, rough roads or rough terrain.

Buffalo Turbine Models CSM2 can easily be transported and conveniently moved from place-to-place. To prepare for transport, follow this procedure:

1. Be sure all bystanders are clear.
2. Ensure unit is properly connected to the towing vehicle.
3. Be sure that all tires, lights, reflectors and SAFETY equipment required by the local highway and transport authorities are in place and are clean and visible by overtaking and oncoming traffic.
4. It is not recommended that the machine be transported faster than 45 mph (70km/h). Slow down for corners or rough roads and terrain. Always retain control of the vehicle.

4.9 Transporting the Model CSM2

1. **Trailer Receptacle (trailer pkg only)**
Recommendation: Class II (minimum capacity 3500 lbs). Do Not Exceed 45MPH At Any Time.
2. The Model CSM2 with the trailer package may be transported on a flat bed truck. Be sure to block the wheels and fasten securely. **NEVER ANCHOR THE SPRAYER OVER THE TOP OF THE TURBINE**
3. **When mounting the unit on a flat bed or pick up truck, securely STOP and CLAMP in the 4**

4.10 STORAGE

Daily cleaning is recommended especially if corrosive materials are being used.

At the end of the working season or storing the unit for a period of time, prepare the machine by following this procedure:

1. Select a storage area that is dry, level and free of debris.
2. Thoroughly wash the machine, including the tank, with a water hose to remove all debris and residue.
3. Lubricate all grease fittings with one shot of grease to displace any accumulated water.
4. Run the machine at low RPM to dry the Blower Components
5. Touch up all paint chips and scratches to prevent rusting.
6. Inspect for worn or failed components. Order the replacement parts now and repair when the time allows, eliminating unnecessary down time at the start of next season.
7. Store in an enclosed building. If space is not available, cover with a waterproof tarpaulin and tie it down securely.
8. Store the machine away from the areas of human activity.
9. Do not allow children to play around the stored unit.

Model CSM2

Wash the Blower unit, then run at lower rpm's to dry blower and engine. Change oil per manufacturer's specs. Spray a lubricant on the nozzle base to ensure smooth operation and the prevention of rust. Park and block unit so the tires clear the ground.

5. SERVICE AND MAINTENANCE



MAINTENANCE SAFETY

1. Set the unit on a level surface, stop engine, set park brake, remove ignition key and wait for all moving parts to stop before attempting to service, adjust or repair.
2. Reinstall and secure all shields removed for servicing before starting to use machine again.
3. Securely support machine with blocks or safety stands when changing tires or working beneath it.

5.1.2 GREASING

Refer to Section 5.1.1 for recommended grease. Use the Maintenance Checklist provided to keep a record of all scheduled maintenance.

1. Use only a hand-held grease gun for all greasing. Air powered greasing systems can damage the seals on bearings and lead to early bearing failure.

IMPORTANT

Over-greasing can damage bearing seals. A damaged seal will lead to early bearing failure. Replace all damaged bearings with factory ordered parts.

2. Replace and repair broken fittings immediately.
3. If a fitting will not take grease, remove and clean thoroughly. Also clean lubricant passageway. Replace fitting if necessary.

5.1 Service



5.1.1 FLUIDS AND LUBRICANTS

1. Grease (Models CSM2)

Use SAE multi-purpose high temperature grease for all applications. SAE multi- purpose lithium base grease is also acceptable. A Teflon spray type lubricant on the nozzle base and nylon slides provide for freer rotation.

USE ONLY CLEAN LUBRICANTS

2. **Model CSM2:** Change oil per Manufacturer's specs (provided with manual).



Model CSM2 plumbing set up

This schematic is only a guide.

This schematic reflects the early designed Model CSM with dustbin only

5.1.4 SERVICE RECORD

See Lubrication and Maintenance sections for details of service. Copy this page to continue record.
See separate insert for optional dustbin maintenance.

CODE: LUBRICATE (L) / CHECK- (*) / CHANGE-(C) / REPLACE- (B) / CLEAN- (CL)

SCHEDULED MAINTENANCE HOURS

SERVICED BY

MAINTENANCE

8 hrs or daily

(*) Engine Oil- Follow Manufacturers Specs

(CL) Liquid Tank, nozzle tips and screens, strainer, Optional Dust Bin

40 hours

(L) Bearing, End

(L) Pillow block bearings - greasing

(L) Nozzle base and nylon slides (spray, i.e. Teflon)

(*) Belt tension- SEE SECTION 5.2.1.

80 hours

(CL) General Filter Cartridge - nozzle tip screens or as needed

(CL) External engine fuel filter - see engine manual

100 hours

(L) Pump Grease Fitting on cam bearing – Use Moly Lithium or equivalent grease. With a flat tool, apply a generous dab of grease to the outer diameter surface of the cam bearing at the top and bottom, where the bearing contacts the connecting rod. (see HYPRO pump insert)

(L) Dust Bin—see form PB-10-10-77 in the back of this manual

(CL) Turbine Blades and Vanes

200hrs or annually

(CL) Machine—Clean Turbine blades and vanes - keep turbine free of debris and grime

(L) Grease and lubricate all fittings including nozzle base.


(L) Wheel Bearings (trailer model)

5.2 Maintenance

5.2.1 Belt Tension

Efficient machine operation requires that the belts always be properly tensioned.

V -belts B32 and B43 are used to drive the pump (shown below).



To adjust belt #1 (B43), loosen bolts on bearing #3 then move bearing in the direction of the arrow. Tighten bolts securely and check for proper tension.

To adjust belt #2 (B35), loosen pump mounting bolts at the base of the pump and move in the direction of the arrow. Tighten bolts securely and check for proper tension.

Always check the pulleys and jack shaft alignment after any adjustments are made.

Replace belts that are broken, worn or stretched.

5.3 Changing the Belts

After using the Model CSM2 for a long period of time, the belts will stretch and wear. To change belts, follow this procedure:

1. Turn off engine and remove key for **SAFETY**. Remove the guards around belt and pulleys.
2. Refer to the picture section 4.2.1 for changing the belts.
To replace belt #1 (B43), loosen bearing #3 then slide the bearing toward the out put shaft of the engine.
The center section of the coupling (#5) will have to be removed in order to remove the old belt and install a new one. Page 28 has a detailed picture of the coupling.
The center section of the coupling must be disassembled and assembled with extreme care. Damage to the coupling can result in premature bearing failure in the turbine and engine. A new bolt kit for the coupling is recommended before reassembling the coupling. ALWAYS USE TOPLOC NUTS. Remove the bolts from the coupling (2 ea. side of flange). Loosen setscrews on one flange only. A thread lock material is used on the threads at assembly. Heat may be needed to break that bond. Clean all dirt and rust that has accumulated on the shaft (behind the flange) then slowly wedge the center section off of the flange. Note: The flanges are counter bored to match the flange bushings. Once the center section is removed, belt #1 can be removed and a new belt can be installed. DO NOT TENSION THE BELT UNTIL THE CENTER SECTION OF THE COUPLING IS INSTALLED.
Bolt the center section per the picture on page 28. DO NOT TIGHTEN THE SET SCREWS AT THIS TIME. Note position of bolts and locking nuts. Once the coupling is installed and securely tightened, check to see if the key is in position on the shaft and in the keyway of the flange. Coat the setscrews with Loc Tite (red) and securely tighten. Re check all the setscrews and coupling bolts before proceeding.

3. To replace belt #2 (B32), loosen mounting bolts (#5) under the pump and slide toward the Turbine. Remove old belt then install the new belt. Adjust the belt tension by sliding the pump assembly away from the Turbine Assembly. See section 4.2.1. in the previous section for more information. Check the pulley alignment and recheck both belts and the tightness of all bolts and set screws. ASSEMBLE ALL GUARDS BEFORE OPERATING UNIT!
4. To replace (4L870) dustbin belts (optional dust bin models only) remove dustbin cover. Remove two 3/8" bolts on jackshaft right side bearing. Slide old belts off. Replace with new belts and reinstall two 3/8" bolts in pillow block, apply pressure straight down on jackshaft to give proper belt tension and tighten pillow block bolts. Reinstall guards.

5. Install all guards before operating blower unit!

6 TROUBLE SHOOTING

The Buffalo Turbine Model CSM2 uses a high volume and velocity of air to apply concentrated sprays and or dust. It is a simple and reliable system that requires minimal maintenance.

In the following section, we have listed many of the problems, causes and solutions to the problems that you may encounter.

If you encounter a problem that is difficult to solve, even after reading through this trouble shooting section, please call Buffalo Turbine, your local dealer or distributor. **Before you call, please have the Operator's Manual and the serial number from your Model CSM2 ready.**

PROBLEM	CAUSE	SOLUTION
Blower does not turn	Engine not running Engine running Sheared key	Start Engine Replace broken belt Replace key on sheave
Engine will not start	Dead battery Battery cables dirty or disconnected Fuel valve shut off	Charge or replace battery Clean and connect terminals Turn on fuel valve
No liquid spray	Toggle switch not turned on Holding tank plugged or empty Loose or broken belt Pulleys slipping Defective solenoid Defective or worn pump Dirty cartridge filter or nozzle screens	Turn switch on from control panel Check hoses and fill tank Adjust or replace belts Tighten set screws on pulleys Replace solenoid Rebuild or replace pump Clean or replace mesh filters
Dust Bin troubles	Clutch not engaged Dust packing solid Loose or broken belts Pulleys slipping Inconsistent application	Turn switch on from control panel See form PB-82/check agitators Adjust or replace belts Tighten set screws on pulleys Check and clean control gates
Belts or pulleys overheat	Belts slipping	Adjust belt tension
No air flow	Blower fan not turning Blower fan turns Air intake or exhaust restricted	See solutions above Turn off engine and remove any debris restrictions
Machine vibrates	Bearing failure Out-of-balance	Replace bearings Check for damaged blades or vanes in the blower unit

7 SPECIFICATION

Model CSM2

Length: (without trailer)	69" with nozzle assembly
Length: (with trailer)	103
Width: (without trailer)	37"
Width: (with trailer)	71"
Height: (without trailer)	42"
Height: (with trailer)	62" (with Dust Bin 80")
Weight: (without trailer)	725lbs.
Weight: (with trailer)	1100lbs.
Weight: (with Dust Bin only)	N/A
Weight: (with Dust Bin and Trailer Pkg.)	1400 lbs
Fuel Capacity:	6 Gallons
Electrical System:	12V Battery (negative ground)
Input Power:	25hp Kohler Command PRO
Input RPM:	3600 RPM
Outlet Size:	12"
12 volt Control Valve	150 PSI (maximum)

MODEL CSM2G PARTS LIST


(Trailer parts listed separately)

Ref. Page#	Qty.	Description	Part #
26	2	Nut, ½ - 13	1231
26	4	½ Lockwasher	1222
26	1	Actuator Mounting Pin Bracket	1451
26,29	2	Cotter Pin, 3/16 x 1 ½	1194
26	1	Actuator, 4"	1409
26,29	20	Nyloc Nut, ¼ - 20	1125
26	2	Cotter Pin, 1/16 x ½	1193
26,29	2	Throttle Lever Pin	1414
26	1	Fuel Tank, 6 gallon EPA/CARB approved	3316
26	1	EPA Cap, Fuel Tank	3314
26	2	Straps, Fuel Tank	1788
28	1	Sight Glass, Brass (SS Tank)	1595
28	1	Tank, 50 gallon SS	5279
27	3	Drain Plug, Tank	1536
28	1	2" NPT GALVANIZED 90 DEGREE STREET ELBOW	3830
28	1	2" NPT GALVANIZED NIPPLE, 5" LG	3831
28	1	Filler Tube Cap, 2" galvanized (SS Tank)	1532
26	1	Transition Guard Sprayer	5320
26	1	Pump Guard	5311
26	1	Battery Box with Cover	1378R
	1	12 volt Battery, min. 300 CCA	1132
26	1	VERTICAL BELT GUARD, DUSTER	5326
26	1	Drive Guard	3733
27	1	Strainer Housing	4154
27	43	Hose ¾"	1732
27	1	Pressure Relief Valve, 3/4	1521
27	1	Manifold Block, Aluminum	1487
27	1	Pressure Gage, 0-300 lbs.	1523
27	1	Solenoid Valve, 12v	1524
28	1	Pulley 3.38 x 1.48, Engine	1586
28	1	Morfex Coupling Complete, Kohler Sprayer	1746
	1	Coupling, Center Section	1256
	4ea.	Coupling, Bolt Kit – (4) 7/16-20x2 ½ HHCS Zinc and (4) 7/16-20 Top loc nuts	1113,1112
	1	Coupling, Flange 1 ¼	1114
	1	Coupling, Flange 1 7/16	1115
	2	Coupling, Key ¼ x 2	1110
28	1	Coupling, Key 3/8	3805
	1	Coupling Set Screws	2869
27	2	Pillow Block Bearing, 3/4	1247
27	1	Jack Shaft, Duster	2222
27	1	Belt, Engine to Jackshaft	5290
27	1	Sheave, BK 100H	1555
27	1	Pump	5297
27	1	Belt, Jackshaft to Pump	5289
27	1	Sheave, BK 90H	3803
27	1	Bushing, H 1	1648



27	1	Sheave, BK 40H	1562
27	2	Bushing, H ¾	1563
27	2	AK25 X ¾ Sheave for Duster	1135
27	2	A-81 V-Belt for Duster	1291
28	1	Engine, CH740 Kohler	3073
28	1	Frame with Cradle	4353
28	2	Rail, Engine	1359
28	3	Slides, Rotation	1138
28	1	Elbow Base, Short	1141
28	1	Belt, Rotation	1142
28	1	Quick Release Clamp Band	4935
28	1	Rotation Motor	1143
28	1	Motor Bracket (Rotation Motor)	1144
28	1	Sheave, AK 32 x ½	1145
28	1	Pump Guide Weldment	5292
28	1	Pump Mount Weldment	5294
28	1	Plastic Nozzle Assy, Sprayer	5530
	1	Nipple, Brass Hex, ½	1594
	1	1/2" PIPE COUPLING, GALVINIZED	3331
29	1	Dust Feed Channel Cover	1987
29	1	RH Blower Assembly	3243
29	1	Granular Bin Sub Assembly	4201
29	1	DUST BIN FOR DUSTER SPRAYER	1982
29	1	LATCH AND CATCH, DUSTER	1767
29	1	HANDLE FOR DUSTER BIN	2224
29	1	DUST BIN GAGE BAR	2212
29	1	ACTUATOR MOUNT, DUSTER	2223
29	1	GAGE BAR POINTER, DUSTER	2213
29	1	DUST BIN MOUNT, FRONT	1983
29	1	Slide Actuator, 2"	1542
29	1	GATE CONNECTING BAR, DUSTER	2220
28	1	Bellmouth	1119
29	1	DUST BIN MOUNT, REAR	1984
29	3	DUST FEED BUSHING, BRONZE	2218
29	4	5/8" SHAFT COLLAR, DUSTER	1568
29	3	DUST FEED SHAFT, VERTICAL	1696
29	9	DUST AGITATOR	1464
29	3	DUST FEED AUGER	1896
29	3	SPACER, VERTICAL DUSTER SHAFT	2219
29	3	DUST FEED GATE FLANGE, CASTING	2211
29	3	DUST FEED GATE, STAINLESS	2210
29	3	DUST FEED STUD, VERTICAL	1519
29	3	DUST FEED CONE	1922
29	2	DUST FEED WIRE SCREW, LONG	1356
29	2	DUST FEED TUBE LONG	1851
29	1	DUST FEED TUBE SHORT	1852
29	3	5/8" PILLOW BLOCK BEARING	1577
29	3	GEAR BLANK FOR DUSTBIN GEAR	1578
29	3	WORM TO FIT 1578	1579
29	1	DOUBLE CLUTCH PULLEY	2216
29	1	DUST FEED CHANNEL, DUSTER	1986
29	1	WARNER ELECTRIC CLUTCH, SF400-5/8-12V	2214
29	1	Dust Feed Shaft, Horizontal	1644
29	1	Short Dust Feed Wire	5337
29	15	¼-20 x ¾" Long Set Screw	2228

27	1	Ball Valve Seal Cap	1244
28	1	Tank Retainer	1728
27	1	¾" Tee, Galvanized	1534
27	1	Valve, Brass Ball, ¾	1525
27	2	Nipple, Brass Hex, ¾	1593
27	3	¾" female couplamatic hose end	1560
27	1	Aluminum Spacer 3/8 x 1-1/2 x 5.1	1597
27	6	Hose clamp	3514
27	1	Pump Adapter	5287
27	1	Pump Extension Adapter	5288
	1	Control Box Assembly 5 switch	1835
	3	Toggle Switches, Momentary (Nozzle & Throttle)	1277
	2	Toggle Switch, On/Off (Solenoid)	1485
	1	Manifold, Nozzle (4 Stations)	1480
	4	Nozzle Body, Brass, ¼ TT (SSCCP1322)	1652
	4	Nozzle Tips, Brass, .035 (SSCTP6502)	1649
	4	Cap, Nozzle Body, Brass, 1/4 NPT (SSCCP1325)	1653
	4	Strainer, Aluminum w/SS Screen (SSC5053-50-SS)	1651
	3	Support Arms, Nozzle Manifold	1307
	6	Jam Nut 1/4 SS, Support Arm	1724
	6	Flat Washer, Support Arm	1725
	4	Nozzle Tips, Brass, .043 (SSCTP6503)	1650
	3	4 x 4 BT Decal	1182
	1	Thrown object, Eye & Ear protection Decal	4725
	1	Caution Do Not Operate Decal	1186
	1	8 x 10 BT Decal	1187
	4	¼-20 x 2-3/4" HHCS	3802
	1	½" x 1-1/2" Galvanized Nipple	3399
	1	3/8-24 x 1-1/2 Faced Head Bolt	3521
	1	Bolt, ½ Pushover	1218
	1	Pump pushover bolt	1727
46		Fuel hose	1158
4		Spacer- 3/8 x 3/16 Thick washer	1106
4		Notched Washer	1139
1		Hour Meter	1372
6		10-32 x 5/8 SHCS	1146
2		1 x ½ x 3/16 Thick Washer	1223
3		3/16 x 1 Roll Pin	1236
4		Nut Plate, 3/8"	1499
6		¾" Street Ell, Galvanized	1528
1		¾" x 2" Galvanized Nipple	1529
2		3/16 Square x 1-3/8 Key	1596
60		½" Goodyear Ortac Hose	1720
1		½" Male Vari Crimp Coupling	2395
2		Galv. Reducing Bushing, ¾ to ½	1530

BT-CSM2G PARTS REFERENCE (BEGINNING W/ SERIAL #40641)



BT-CSM2G PARTS REFERENCE CONT. (BEGINNING W/ SERIAL #40641)




NOTE:

- PART #1732 LENGTHS
- TANK-TO-FILTER - 18 INCHES.
- FILTER-TO-PUMP - 10 INCHES.
- RETURN-TO-TANK - 15 INCHES.

NOTE:

BT-CSM2G PARTS REFERENCE CONT. (BEGINNING W/ SERIAL #40641)



DUST BIN DIS – ASSEMBLY AND ASSEMBLY INSTRUCTIONS

1. Remove the (3) bolts on cover and remove cover.
2. Remove the (4) bolts and nuts on front and rear dustbin mounts.
3. Remove dustbin gate lever.
4. Remove belts from dust -bin clutch and lift dust- bin out of mounting.
5. After removing dust -bin from the sprayer, set dust- bin on a stand with dust- bin tubes pointing up.
6. Remove the (3) bolts on each dust –bin dust -cone assembly and lift off cones and tubes. Check tubes for wear and replace by loosening (2) setscrews in the neck of the cone. Make sure tube slots are at right angles of the air -flow when replaced.
7. Remove the dust twist springs by sliding side ways from holes on dust twist feed stud. Remove dust -twist feed studs and dust- gates.
8. The dust feed flange must remain in bottom of dust- bin. Use bolts to remove and bolt flange in place.
9. Turn dustbin bottom side down.
10. To remove dust clutch, loosen set -screw on collar next to clutch cam. Drive out spring pins and remove. Next remove $\frac{1}{4}$ x 1 Allen head screws from throw-out shaft and bronze shaft collar and remove shaft collar. Loosen set -screw on tandem plate cover and slide clutch from horizontal shaft. Check drive plates on clutch and replace as needed.
11. Loosen set-screws on pillow block bearings
12. Drive spring- pins from gears and shaft and remove gears. Check gears for wear and replace as needed.
13. Remove bolts from (2) end pillow block bearings and lift dust- bin channel from shafts. Check bronze bushings in channel and replace as needed.
14. Check vertical shafts for wear. Replace as needed.
15. Reverse procedures to re-assemble.
16. For lubrication, see general instructions for operation.

LUBRICATION

#1 - #2 - # - #4 - # 5 Dust Bin Lubrication

Use Grade NLGI #2 lithium grease.

Grease every 25 hours

#12 - #13 - #14 Dust Bin Gears

Open gear Hi-Low gear lubrication NLGI # 3

Grease every 25 hours

#7 - #8 - #9 Unit

Multi purpose grease

Grease every 25 hours

#15 Blower

Sealed bearing, no lubrication required

#16 Pump

Use Grade NLGI # 2 Lithium grease. See pump instruction sheet.

Engine oil. Refer to engine manual.

MODEL CSM2

Horizontal Range-Liquid and Dust	125 Feet *
Vertical Range-Liquid and Dust	75-100 Feet *
Flow Rate of Dust	$\frac{1}{2}$ lb. per min (30 lbs. Hr) Minimum * 5 lbs. per min (300 lbs. Hr) Maximum *
Flow Rate of Granular (Good Coverage 70-80 Feet)	3-1/3 lbs. per min Minimum * 40 lbs. per min Maximum *
Flow Rate of Liquid	varies depending on pressure setting, Size of nozzle tips(orifice opening) and number of nozzles being used. (See flow rate chart in the instruction manual)

*These are approximate figures only. Weather conditions, material concentration (powder, liquid and granular) condition of sprayer/duster unit will determine actual disbursement of materials.

USES:

Vector Control- Fly, Mosquito, etc.
Row Crops
Orchards
Grasshopper Control
Weed Control
Fertilizing
Soil Stabilization
Growth Retardant
Fly Control
Mosquito Control
Odor Control
Feed Lots
Disinfecting Buildings, Etc.
Golf Course Work
Shade and Ornamental Tree Work
Odor and Fly Control at Dump and Landfill Sites

SUPPLEMENT A

The Nozzle and pressure chart for application of liquids using the Buffalo Turbine Model CS and CSM2 Sprayer. Application of liquid using 4 nozzles.

<u>GALLONS PER MINUTE</u> (using 4 spray nozzles)	<u>NOZZLE #</u>	<u>PRESSURE (PSI)</u>
.2	650067 - .021(orifice)	20
.24	650067	30
.28	6501 - .026	20
.32	6501	25
.4	6501	40
.48	6501	60
.5	6501	65
.44	65015 - .031	20
.6	65015	40
.72	65015	60
.56	6502 - .036	20
.68	6502	30
.8	6502	40
1.0	6502	60
.84	6503 - .043	20
1.04	6503	30
1.2	6503	40
1.48	6503	60
1.4	6504 - .052	30
1.6	6504	40
2.0	6505 - .057	40
2.4	6506 - .062	40
3.2	6508 - .072	40
4.0	6510 - .078	40
6.0	6515 - .093	40
8.0	6520 - .109	40

Above information are approximate values only

Maximum recommended pressure – 150 PSI
Control Valve part # 1524

MAINTENANCE OF THE BUFFALO TURBINE SPRAYER/DUSTER

The proper care and operation of the Buffalo Turbine Sprayer/Duster will increase the likelihood of obtaining satisfactory control and will largely eliminate the frustration that results from malfunctioning of the machine when time is critical and the machine is most needed.

GENERAL INFORMATION

1. **NEVER** operate or start machine when pump is dry. You will overheat and seriously damage the pistons and seals by doing so. Make sure liquid is in the tank and the liquid line from tank to pump is open.
2. **NEVER** engage dust- bin clutch when dust gates are in a closed position.
3. When using dusts, granules, or pellets it is best to fill the dustbin after reaching the application area, as the jarring from traveling will pack some dust solid.

DAILY MAINTENANCE

1. Check inside of blower, tank, and dust -bin to insure that there are no foreign objects to interfere with moving parts.
2. Check belt tensions.
3. Check for loose nuts or bolts.
4. All lubrication points should be checked to see that they are lubricated. **DO NOT OVER GREASE.**
5. **NEVER LEAVE INSECTICIDE IN THE SPRAYER OVERNIGHT.** Some of the insecticides in use are highly corrosive and will cause damage to the sprayer if they remain in the lines, pump, etc., overnight. Spraying operations should continue until all the solution in the tank has been used. Then the tank should be partially filled with water and the liquid sprayed from the machine until clear water emerges from the nozzles. This flushing operation usually takes 10-15 minutes and **MUST** be carried out at the end of each day's spraying. While this flushing operation is being carried out, the hopper and blower should be washed.
6. The liquid line strainer (liquid filter) should be removed at the end of each day and the screen cleaned before replacing and tightening the tip. Failure to carry out this procedure may result in plugging up the lines completely or inconsistent spray output.

QX-SA SERIES VALVES



F2E33 Valve Kit
with EH3 Actuator



F2F33 Valve Kit
with EH3 Actuator

Valve	Weight*	Ø	A	B	C	D	E	F
E	3.6	¾"	8.6	5.0	4.0	3.3	1.4	1.0
F	3.6	1"	8.6	5.0	4.0	3.3	1.4	1.0

Dimensions may vary for flanged outlet. *Weights approximate in lbs.

Materials List



No.	P/N	Description	Qty
1	QX4-110* QX4-115 QX4-140 QX4-170	Valve Body, 2-Way 1" NPT QH 2-Way 2" SP Flange 2-Way 1" FNPT 2-Way ¾" FNPT	1
2	QX4-119	Seat, PTFE	2
3	207-0001	Stem, SS Inline	1
4	QC3-130	O-Ring, #113, VITON	2
5	QX4-130	Valve Ball, SS	1
6	QX4-161	O-Ring, #123, EPDM	3
7	QX4-118	Donut Seat	1
8	QX4-162	O-Ring, #132, EPDM	1
9	QC3-134	O-Ring, #229, EPDM	1
10	QC3-170	Thrust Washer, PTFE	1
11	QX4-121-3	Stem Retainer Bushing	1
12	QX-103	Hair Pin, SS	1
13	QX4-126 QX4-127* QX4-128	End Cap, 1" QH 1" FNPT ¾" FNPT	1
14	QX4-200	V-Clamp, SS	1
15		EH3 Actuator	1
16	QX-102**	Hair Pin, SS	1
*	QX4-RKT QX4-RKTV	Valve Repair Kit VITON Repair Kit	

Note: Polypropylene standard, nylon available

*Shown in assembly **Not pictured

QX3 and QX4 2-Way

- ¾" and 1" Full Port Valves
- 150 PSI at 70F° (polypropylene)
- 300 PSI at 70F° (nylon)
- Wiring: 12/24V DC and 24V AC
- QX3 ¾" FNPT
- QX4 1" FNPT or QH Fittings
- 2" Standard Port Flange Optional
- QX3 Cv - 51 (51 GPM at 1 PSI drop, water)
- QX4 Cv - 68 (68 GPM at 1 PSI drop, water)
- Refer to Chart A on Page 7 for Cycle Times Available



KZ VALVE
By KZCO Inc.



**ANNOVI
REVERBERI**®
The Power of Experience

**AR 30
AR 40**

140° F - Max Water Temp
1" - Suction AR30
1 1/4" Suction AR40
1/2" NPT - Outlet



INSTRUCTION MANUAL

AR30 - 550 RPM - SEMI-HYDRAULIC TWO DIAPHRAGM PUMP

MODEL	MAX GPM	MAX L/MIN	MAX PSI	MAX BAR	HP POWER	WEIGHT LBS.
AR30-SP	9.6	36.2	580	40	2.9	20.5
AR30-SP/A3/4	9.6	36.2	580	40	2.9	20.5
AR30-GR3/4-GCI	9.6	36.2	580	40	2.9	33.0

AR40 - 550 RPM - SEMI-HYDRAULIC TWO DIAPHRAGM PUMP

MODEL	MAX GPM	MAX L/MIN	MAX PSI	MAX BAR	HP POWER	WEIGHT LBS.
AR40-SP	12.2	46.3	580	40	3.5	20.5
AR40-SP/A3/4	12.2	46.3	580	40	3.5	20.5
AR40-GR3/4-GCI	12.2	46.3	580	40	3.5	33.0

GCI - Pump with a mounted control unit.

DIAPHRAGM KITS

MODEL	DESCRIPTION
AR43285	BlueFlex
AR43283	Desmopan
AR43282	Buna

VALVE KITS

MODEL	DESCRIPTION
AR1917	Valves

O-RING KITS

MODEL	DESCRIPTION
AR1916	O-Rings

OIL

MODEL	DESCRIPTION
AR64532D	Oil
AR64532D-C	Case (6)Oil


AR 30 AR 40



**AR30-SP
AR40-SP
Pump with Base**



**AR30-SP/A3/4
AR40-SP/A3/4
Pump with
3/4" Thru Shaft**



**AR30-EM230-1
3 HP 230 Volt
Single Phase Motor**



**AR30-GR3/4-GCI
AR40-GR3/4-GCI
Pump with Gearbox &
Control Unit**



**AR30-CR3/4-GCI
AR40-CR3/4-GCI
Pump with Gearbox
& Control Unit**




Drive Options

Gearbox Kit AR1666: 3/4" for 5-6 HP Gas Engines




Gearbox for four stroke engines with SAE J609a flange



Gearbox Kit AR1636: 3/4" for 5-6HP Gas Engine




Gearbox for four stroke engines with SAE J609a flange



Shaft Kit AR43393: 1 3/8" 6 Splined Shaft




1 3/8" universal shaft



Shaft Kit AR43394: 1 3/8" 6 Spline Female




1 3/8" female



Pulley Kits



Pulley



Kit Appl. P AR1504 11" 2A

Kit Appl. P AR1495 12.2" 2A

Kit Appl. P AR1520 12.2" 3A

Hydraulic Motor Flange Kit



AR43397

For models AR30, AR50, AR303, AR403, AR503 (SP Models Only)

Fits SAE 2-bolt A Flange Motors with 1" Shaft

Shaft Kit: 1" Male Solid Keyed Shaft



AR43387 - for model AR30
AR43388 - for model AR50
AR43390 - for model AR503, AR303, AR403

Kit includes a male 1" keyed shaft adapter, mounting bracket and necessary hardware.

Shaft Kit 1 3/8" Female PTO Kit AR1704





For model AR30, AR50



Electric Motor Drive

AR30-EM230-1
3 HP 230 Volt Single Phase Motor
4 Pole 1700 RPM Operation
IP54 Protection Against Rain and
Splashing Water.



L1 AND L2 ARE THE TERMINALS FOR THE CONNECTIONS OF THE WIRES FROM THE POWER CABLE

AR30-EM230-1 550 RPM - SEMI-HYDRAULIC TWO-DIAPHRAGM PUMP						
MODEL	GPM	L/MIN	PSI	BAR	Amp Draw	WEIGHT LBS.
AR30-EM230-1	9.2	36.2	0	0	5.8	69.5
	8.9	33.7	200	14	10	
	8.6	32.5	400	28	15	



Control Unit GI40 & GIC40

GI40 and GIC40 Control Units:

Control units are available for easy flow and pressure control of your sprayer system. These units include a manual dump valve and adjustable pressure relief valve to control pressure, a liquid-filled pressure gauge to monitor pressure, and shut-off valves to control flow.



Control Unit Operation


- On pumps AR30 and AR40, adjust the pressure by clamping the relief valve adjustment lever down.
- With the bale hook in the number one position, the pressure is about 100 psi; number two is about 250 psi; number three is about 450 psi; number four is about 550 psi.
- These pressures can be adjusted by using the fine adjustment knob located on top of the relief valve spring. The fine adjustment knob can be rotated when the relief valve lever is in the up position.
- On pumps AR30 and AR40, the pressure is released by lifting up the relief valve adjustment lever with the bale hook on the number 1 position.

Fine Adjustment Knob

Pressure Adjustment & Release Lever

Pressure Gauge

Bypass Return Outlet
(Connect directly to the tank without restrictions or ball valves.)



Hose Barb Outlet 2 Places



Intended uses

The pump is designed and constructed for incorporation in plants and machinery (spraying machines for the protective treatment of agricultural crops and garden plants). **All other uses constitute misuse unless approved by the manufacturer's technical service**

The pump must be used in a manner appropriate to its technical data (see "Technical Data"), and must not be modified or improperly used.

Misuses

Do not put the pump into service until the plant or machinery in which it is incorporated has been declared compliant with the relevant national and local legal requirements.

Do not use the pump in a potentially explosive atmosphere.

Do not use the pump for **flammable**, toxic or corrosive liquids or liquids with unsuitable density, especially **seawater, adhesives, bitumens, asphalt sealers, two-step curing compounds, concrete sealers, liquefied gases or solvents** of any kind, paints of any kind or liquids containing solids in suspension, and in all cases **do not** use with any liquid unless certain that it is compatible with the materials used in the pump circuit.

Do not draw in liquids at temperatures above 50°C or below 5°C.

Do not use the pump in drinking water supply systems.

Do not use the pump on products for human consumption.

Do not use the pump on pharmaceutical products.

Do not use the pump without first checking that the intake and delivery circuit pipelines are correctly secured and free from leaks.

Do not use the pump without the safety devices provided: guards for shafts and drive couplings and suitably rated relief valve on the delivery circuit.

Do not use the pump to wash or spray: people, animals or delicate items, live electrical equipment or chemicals whose characteristics are not known.

Safety devices




Danger - Warning

Never tamper with or by-pass the safety devices. Maintain all safety devices regularly to ensure they all work efficiently.

The drawing shows the position of the safety devices mounted on the machine.

Additional safety devices must be added as necessary during the design phase (see "Installation information").

A) Fixed guard: provides protection against accidental contacts with the drive shaft when in operation.



Residual risks


Even if the safety regulations and information provided in the manual are complied with, the residual risks described in the declaration of incorporation still apply when the pump is in operation.



INSTALLATION INSTRUCTIONS

Installation diagram (guideline)


The following is a simplified illustration of the typical installation layout and is purely guideline.



General guidelines on water supply connection

To operate correctly, the diaphragm pump must draw in liquids from containers at atmospheric pressure. **Do not supply the pump with pressurised liquids.**

For continuous duty, the pump should not draw in water by gravity from containers with liquid level at heights above 3 m.



For continuous duty, the pump should not draw in liquids by vacuum from containers with the liquid level more than 3 m below the pump intake fitting and the circuit must consist of hoses of length and diameter appropriate to the pump intake fitting (see "Technical Data"), free from restrictions and elbows, and with a filter of suitable capacity (see "Installation").

For occasional duty, such as filling water supply tanks, the pump can be operated at a vacuum drawing in liquids from reservoirs having the surface of the liquid up to 5 m below the pump intake fitting, for periods of no more than 15 minutes.

Drawing in liquids from lower levels or for longer times causes cavitation in the pump circuit and reduces the lifetime of the diaphragms, valves and mechanical parts.



Safety recommendations for handling and lifting

Before starting the operations, organise the intended working area so that the materials can be lifted and handled in safety.

Unloading, loading, handling and lifting operations must be carried out by skilled, authorised, specifically trained staff.

During lifting and handling operations, the people not involved in the operations must remain at a safe distance.

For lifting, use hooks and ropes which are free from damage and appropriate for the load to be lifted.

Packaging description and unpacking

The packaging normally consists of a cardboard box for easy, safe transport.

Depending on the quantity of goods to be shipped and the place of destination, packages may be fixed on a pallet for easier lifting and handling.

Check the weight of the item on the transport documents to allow the use of suitable lifting equipment.

When unpacking, check that all components are present and intact. If items are missing or damaged, contact the dealer or manufacturer to agree the procedures to be followed.

The packaging material must be disposed of appropriately in accordance with the relevant statutory requirements.

Transport

The pump may be shipped by a variety of means of transport (road, rail, sea or air) depending on its destination. Secure the packaging firmly to the vehicle during transport, to prevent random movement.

Storage

In the event of a lengthy period out of use, place the pump (in its packaging if possible, or otherwise protected) under cover, protected from the weather.

Do not store in places where the ambient conditions might impair the pump's operating condition over time.

Safety recommendations for installation

Take all possible precautions to allow the pump to be installed in a safe, risk-free manner.

All installation phases must be taken into consideration when designing the machinery or plant in which the pump is to be installed.

The design must consider all mounting points, the means of transmission of the energy sources, and the protective and safety devices required by the relevant regulations to prevent the risk of injury.



INSTALLATION INSTRUCTIONS


Installation

- The crankshaft may turn in either direction.
- The water connection with the pump must be made using hoses of suitable diameter, in all case no less than that of the pump fittings, securing them to the fittings using good quality clamps. The intake hose must be coil-reinforced to prevent restrictions.
- The pump inlet must be fitted with a filter having suitable capacity for the pump delivery rate and must be designed to generate a vacuum of no more than - 7 Hg. This value can be measured by connecting a vacuum gauge to the pump intake fitting.
- The rated pressure of the outlet hose, fittings and clamps must be no less than the maximum rated pressure of the pump. Replacing the intake and outlet fittings provided on the pump by the manufacturer with smaller diameter alternatives may reduce the pump's performance and void the warranty.

Mounting the pump

The pump must be installed on a horizontal surface with no flexible components between it and the mounting surface.

The illustration shows the maximum permitted pump installation angle beyond which proper lubrication of the crank mechanism is not ensured.



Fix the pump by bolting the pump base onto the machine with suitable bolts, tightening appropriately.



Safety recommendations for use

Before start-up, the operator must perform the necessary safety checks.

In the event of leaks from the pressurized pipes, stop the pump at once and fix the leak.

Do not operate the pump above the limits set by the manufacturer to increase its performance.

Preliminary checks

If the pump has a pressure accumulator, check its level of inflation, see "Checking the inflation pressure".

Check the fittings of the hoses and the pump's intake and delivery circuits to prevent restrictions, the intake of air and leaks of liquid.

Check the pump tank oil level as described in the "Checking the oil level" section.

Before putting the pump into operation, check that the control unit is set for low pressure with the adjustment lever released.

Starting and stopping the pump

To start the pump, proceed as described below.

1. When starting the pump, keep the control unit lever in the full bypass position until the pump has primed.
2. After starting the pump, and after the pump is primed, move the control unit lever into the pressure regulation position desired.
3. During the first few hours of operation, check that the oil level in the tank remains between the minimum and maximum limits. If top-ups are required, use A/R diaphragm pump oil, AR64532D.

To stop the pump, proceed as described below.

1. Reduce the pressure by releasing the control unit lever.
2. Stop the pump.



MAINTENANCE INSTRUCTIONS

Safety recommendations for maintenance



Caution - Take Care

Before doing any maintenance work, depressurise the water system and isolate the pump from all energy sources.

When the jobs are done, before restarting the pump, check that no tools, rags or other materials have been left close to moving parts or in hazardous zones.

Replace any excessively worn components with original parts and use the lubricants recommended by the manufacturer.

Scheduled maintenance table			
Frequency	Component	Procedure	Reference
Every working day	Filter	Inspect filter cartridge	See "Inspecting the filter"
	Pump	Checking the oil level	See "Checking the oil level"
	Connection of pump to power source (pulley, belt, coupling)	Inspection	-
	Pump	Inspect mounting	See "Inspecting the pump mounting"
	Pipes and connections	Inspection	See "Inspecting the connections and pipes"
Every 100 working hours	Pressure accumulator (if installed)	Check inflation pressure	See "Checking the inflation pressure"
	Reduction gear (if installed)	Check oil	See "Checking the oil level"

Dispose of the worn-out components and lubricants in accordance with the relevant statutory requirements.

Carry out the routine maintenance procedures specified by the manufacturer to keep the pump safe and performing well.



Table of lubricants

The pump is delivered complete with high-performance 30 weight, non-detergent oil suitable for the intended ambient conditions (see "Environmental operating limits").

Inspecting the pump mounting

Check that the pump's fixing screws have not become loose.

If necessary, tighten them with the driving torque stated in the installation design.

Inspecting the connections and pipes

- **Inspect the connections for leaks.**

Leaks can normally be dealt with by tightening the connections properly.

If leaks from the intake pipeline connections are noticed, the seals must be repaired.

- **Inspect the hoses.**

If the pipes show signs of aging, breakage, swelling, rubbing, etc., they must be replaced.

Inspecting the Filter


- **Inspect the filter cartridge.**

If the cartridge is fouled, wash it thoroughly to remove the dirt.

If the cartridge is torn or cracked, it must be replaced.

Checking the oil level

- Check the oil with the pump level, ensuring that it has been running for at least 5 minutes in normal working conditions.
- If the oil level is not between the MIN and MAX marks on the tank, add or remove oil to restore this level and check, still with the pump running, that the oil level does not vary so much that it leaks from or is no longer visible in the tank.
- If necessary, top up with oil with A/R Premium Diaphragm Pump oil.
- Check the oil level regularly, as it may vary significantly with the operating conditions.




To top up with oil proceed as described below.

- 1) Unscrew the cap (B) and pour in oil (C).
- 2) Screw the cap (B) back into place.



A/R Pump Oil
P/N AR64532D
Specifically Formulated for
A/R Diaphragm Pumps



- Advanced Lubrication Technology
- BlueFlex® Diaphragm Compatible
- SAE 30 Non-Detergent Oil







Checking the inflation pressure

If the pump has a pressure accumulator, check its level of inflation, with the pump shutoff using an air chuck fitted with a pressure gauge. The accumulator is inflated by the manufacturer for use of the pump at its maximum pressure. For adaptation of the accumulator pressure to the working pressure, refer to the table below.



			
bar	psi	bar	psi
1-3	15-44	1	15
3-12	44-174	1-3	15-44
12-20	174-290	3-5	44-73
20-50	290-725	5-7	73-102



MAINTENANCE INSTRUCTIONS

Pump Storage

It is important to comply with the recommendations for storage in the operator's manual of the machine into which the pump is incorporated.

For the pump itself, at the end of pumping operations it is essential to flush out the internal circuit by pumping clean water. After this, open the intake circuit to the air and leave the pump in operation until the internal circuit is completely empty. Following this simple procedure at the end of every operating session will prevent the retention inside the pump of products which are often corrosive and may damage its liquid circuit over the long-term.

If the pump is in storage during the winter in locations with severe weather conditions, it is very important to flush out the internal circuit as described above and then fill the pump with A/R Pump Saver, AR64511. Then take care to drain the liquid from the system and the pump.

Putting the pump back into service

Before putting the pump back into service after storage, check the oil level and the tightness of the mounting screws.

Scrapping the pump

Used units must be disposed of in compliance with local legislation.



A/R Pump Saver

P/N 64511

Protects Pumps from
Freezing Conditions



TROUBLESHOOTING



The information provided is intended to provide guidance how to deal with malfunctions which may occur during use.

Some of these procedures may be carried out by skilled staff, while others have to be performed at specialised service centres since they require the use of specific equipment as well as detailed knowledge of repair operations.

Problem	Cause	Remedy
The pump does not prime properly.	Intake circuit not airtight.	Tighten, repair or replace hoses and fittings as necessary.
	Control unit switching lever on "Pressure" setting.	Move control switching lever to "By-pass" setting.
The pump does not require the required pressure.	Seat and plate of intake and delivery valves worn.	Replace the worn valves.(1)
	Nozzles worn or too large in diameter.	Replace the worn nozzles. Use nozzles of suitable diameter.
	Restriction in intake circuit.	Remove the restriction from the circuit.
	Intake filter fouled.	Clean the filter cartridge.
Pressure gauge needle wobbles, pressure pulsating.	Intake circuit not airtight.	Clean or replace the intake and delivery valves. (1)
	Residual air left inside pump.	Discharge the air by opening a ball valve/central unit connected to the delivery side with the pump in operation.
	Valve plate stuck to its seat.	Tighten, repair or replace hoses and fittings as necessary.
	Pressure accumulator deflated	Inflate accumulator to the correct pressure.
Uneven flow of liquid to nozzles.	Pressure accumulator deflated	Inflate accumulator to the correct pressure.
Increase in noise and simultaneous drop in oil level (pump cavitation).	Restriction in intake circuit.	Remove the restriction from the circuit.
	Intake filter fouled.	Clean the filter cartridge.
	Pump drawing in liquid from too low a level.	See "Pump Intake Conditions" section.









TROUBLESHOOTING



Problem	Cause	Remedy
Oil on pump body or base.	Oil seal on pump shaft worn.	Replace the worn oil seal.
	Oil pressure inside pump too high.	Restore correct oil level in tank.
Pump using too much oil (oil flowing from delivery port) or oil whitish in color (water/oil emulsion in tank).	One or more diaphragms ruptured.	Stop the pump at once. Replace the diaphragms (1)

A.R. NORTH AMERICA

AR 30 / AR 40



AR 30 / AR 40


	SP	SP/A3/4
AR30	31732	31733
AR40	33044	33045

Pos	Code	Description	Qty	Note
1	620011	Pump body	1	
2	620101	Head	1	
3	620102	Head	1	
4	621430	Bolt TE M12x55	8	T445*
5	620080	Diaphragm	2	NBR
	620081	Diaphragm	2	Viton
	620085	Diaphragm	2	Desmopan
	620082	Diaphragm	2	BlueFlex™
6	620120	Piston Ø 56	2	
7	620140	Connecting-rod	2	
8	620110	Sleeve	2	AR30
	622190	Sleeve	2	AR40
9	580470	Ring connecting rod	2	
10	380300	Pin	2	
11	380080	Ring circlip Øi 14	4	
12	160230	Piston ring	2	
14	1040180	Retaining washer	2	
15	580360	Hub pin	2	T180*
16	180150	Nut M10	2	T350*
18	620030	O-ring Ø 25.80x3.53	4	
	620031	O-ring Ø 25.80x3.53	4	Viton
19	629050	Valve	4	
20	111120	Ring circlip Øi 47	2	
21	620020	Cover	1	
22	620210	O-ring Ø 40.95x2.62	1	
23	620291	Ring circlip Øe 20	1	
24	620191	Bearing	1	
25	850850	Bolt TCEI M6x30	2	T90*
26	550331	Washer	2	
28	180101	O-ring Ø 17.5x2	2	
29	550030	Oil sight glass	1	
30	550040	O-ring Ø 26.65x2.62	1	
31	550050	Cap Orange	1	AR30
	550052	Cap Black	1	AR40
32	620160	Spacer	1	
33	550060	Bushing	1	
34	620130	Ring seal	1	
35	620330	Ring circlip Øi 65	1	
36	620170	Shaft	1	(N) AR30
	622200	Shaft	1	AR40
37	620150	Manifold	1	
38	550340	Fitting 1" G M-M	1	AR30
	450120	Fitting 1" G - 1 1/4" G M-M	1	AR40
39	550350	O-ring Ø 23.81X2.62	1	AR30
	390290	O-ring Ø 29x3	1	AR40
40	550242	Ring nut 1" G	1	AR30
	550870	Ring nut 1 1/4" G	1	AR40
41	550370	Elbow 1"	1	AR30
	580040	Elbow 1 1/4" G	1	AR40
42	390060	O-ring Ø 20.63x2.62	4	
44	621780	Bolt TE M8x40	8	T180*


Pos	Code	Description	Qty	Note
45	620230	Semi air chamber upper	1	Red
	629211	Semi air chamber upper / w-air valve	1	
46	550194	Air chamber Diaphragm	1	BlueFlex™
	550190	Air chamber Diaphragm	1	NBR
47	622070	Semi air chamber lower	1	
49	650542	Gasket	1	
50	180020	Air valve	1	
51	390290	O-ring Ø 29x3	1	
52	620680	Key	1	For 620172
53	620172	Shaft marked P	1	ø 20 mm (P) AR30
	620174	Shaft marked R	1	ø 3/4" (R) AR30
	622210	Shaft	1	ø 3/4" (R) AR40
54	659209	Diaphragm Chamber Assembly	1	NLA
	659213	Inlet pulsation Chamber	1	
55	620661	Flange	1	
56	620670	Washer	1	
57	180370	Bolt TE M8x25	1	T180*
58	620630	Ring seal	1	
59	620021	Cover	1	
60	650660	Diaphragm holder anodized	1	NLA Obsolete
61	650670	Diaphragm	1	NBR
	650671	Diaphragm	1	BlueFlex™
62	651670	Clamp	1	
63	1500350	Shield	1	
64	820670	Bolt TCEI M10x16	4	T90*
65	620190	Bearing	1	
66	880530	Plug 3/8" G	1	T180*
67	740290	O-ring Ø 14x1.78	1	
68	620930	Spacer	1	
69	620940	Spacer	1	
70	380230	Bearing	1	
71	380210	Bolt TE M8x75	2	T265*
72	380240	Nut M8	2	
73	380200	Base	2	
74	390270	Nut M8	2	T180*
75	450145	Flange	1	
76	110130	Ring nut 1/2"	1	
77	46730	Inlet pulsation damper assembly	1	
87	550350	O-ring Ø 23.81X2.62	1	

* Torque: in-lbs +/- 10%

Repair Kits



AR 43282 Buna diaphragms	
AR 43285 BlueFlex™ diaphragms	
AR 43283 Desmopan diaphragms	
Pos.	Qty
5	2
18	4
46	1



AR 1917 Valves	
Pos.	Qty
18	4
19	4



AR 1916 O-Rings	
Pos.	Qty
18	4
22	1
28	2
39	2
42	4
49	1
51	1
67	1




Suggested oil	
Type	Oz
AR64532D	32

Crankcase Oil
Capacity 26 oz

Medium pressure

A.R. NORTH AMERICA

GI 40 / GIC40



94 - 6

Pos	Code	Description	Qty	Note
1	620220	Relief valve body	1	
2	130171	Plug 3/8" G	1	T180*
3	130491	Ball valve 3/8" G - 1/2" G M-M DX	2	
4	390270	Nut M8	2	T180*
5	450110	Seat	1	GI40
6	450112	Seat	1	GIC40
7	550350	O-ring Ø 23.81X2.62	2	
8	550545	Pressure gauge	1	0-1150 PSI
9	180370	Bolt TE M8x25	2	T180*
10	320420	Spring	1	
11	110121	Seat	1	Desmopan
12	110120	Seat	1	Buna
13	110122	Seat	1	Viton GI40
14	450112	Seat	1	Ceramic GIC40
15	320433	Stem	1	
16	320511	O-ring Ø 37.8x4	1	
17	390140	Gasket	1	GI40
18	390141	Gasket	1	Viton GIC40
19	550460	Elbow 3/4"	1	
20	550440	Fitting 1/2" G - 3/4 G M-M	1	
21	320410	Body valve	1	GI40
22	320411	Body Valve	1	GIC40
23	320480	Hub pin	2	
24	320460	Fork	1	
25	320470	Lever	1	
26	320490	Support	1	
27	320450	Retaining washer	1	
28	320440	Ring nut	1	
29	110190	Spring	1	
30	230120	Retaining washer	1	
31	320406	Bracket	1	
32	450145	Flange	1	
33	550450	Ring Nut 3/4"	1	
34	160660	Bolt TE M8x35	2	T90*
35	880830	O-ring Ø 15.54x2.62	1	
36	180101	O-ring Ø 17.5x2	1	
37	110131	Ring nut / HB 1/2" x 3/8"	2	Optional
38	110130	Ring nut / HB 1/2" x 1/2"	2	
39	1040790	Ring nut 3/4" G	1	o
40	1150580	Hose barb Ø 13	1	o
41	130492	Ball valve 3/8" G - 1/2" G M-M SX	1	


Pos	Code	Description	Qty	Note
44	329202	Seat Guide assembly	1	GI40
47	1923	Valve kit Adjustment	1	GI40
o Not included				
* Torque: in-lbs +/- 10%				

AR 1757 Viton valve seats (GI40)		AR 1925 Desmopan valve seats (GI40)		AR 46016 Ceramic valve seats (GIC40)	
Pos.	Qty	Pos.	Qty	Pos.	Qty
5	1	5	1	5	1
10	1	10	1	10	1
11	1	11	1	11	1
12	1	12	1	12	1
13	1	13	1	13	1
14	1	14	1	14	1


GI 40 / GIC 40

For GI 40

KIT 977 "I"



KIT 982 "S"



KIT 980 "S"

Build-in control unit and remote control

AR 977 "I" Build in control

Pos.	Qty	Pos.	Qty
15	1		
31	1		
36	1		
39	2		

For AR 30 - AR 50 - AR 303 - AR 403

AR 980 "S" Remote control

Pos.	Qty	Pos.	Qty
3	1		
4	2		
6	1		
15	1		
28	1		
30	1		
31	1		
32	1		
33	2		
36	1		
39	3		

For AR 30 - AR 50 - AR 303 - AR 403

AR 982 "S" Remote control

Pos.	Qty	Pos.	Qty
3	1	41	1
4	2	42	1
6	1		
15	1		
28	1		
30	1		
31	1		
32	1		
33	2		
36	2		
39	3		

For AR 503


Control units

A.R. NORTH AMERICA

AR 1636 : Gear Reduction

Per - For: AR 30 - AR 303 - AR 403

Ø 3/4" Straight Keyed Shaft



90 - 1

Gear boxes

Pos	Cod.	Description	Q.ty	Note
1	620561	O-ring	Ø 78x2,5	1
2	180030	Bolt	TCEI M8x20	1
3	621000	Adapter Flange		1
4	620990	Bearing		1
5	651620	Gear	Z=64	1
6	200231	Washer		3
7	620470	Bolt	TCEI M10x20	3
8	620960	Body		1
9	1980740	Plug	3/8" G brass	3
10	740290	O-ring	Ø 14x1,78	3
11	651000	Bolt	5/16"x24UNFx1"	4
12	621010	Bolt	TCEI M10x75	4
13	1140370	Plug		1
14	621660	Pinion	Z=11	1
15	320240	Ring	circlip Øe 40	2
16	961780	Bearing		1
17	961790	Ring	circlip Øi 68	1
18	961800	Oil seal		1
19	881090	Key		1
20	620950	Gasket		1



Suggested Oil

Type

90 W Gear Lube

For gas engine with 3/4" shaft, flange SAE J609a


*Torque: in-lbs +/- 10%

A.R. NORTH AMERICA

AR 1666 : Gear Reduction

Per - For: AR 30 - AR 303 - AR 403

Ø 3/4" Straight Keyed Shaft



94 - 1

Pos	Cod.	Description	Q.ty	Note
1	540331	Seal	1	
2	200390	Snap ring	Øi 62	1
3	621130	Bearing		1
4	2960050	Bolt	5/16" 24 UNF 2B	1 T177*
5	2960020	Body		1
6	740290	O-ring	Ø 14x1.78	4
7	1980740	Plug	3/8" G brass	1
8	390450	Bolt	M8x30	6 T177*
9	2960070	Plug		1
10	2960060	O-ring	Ø 177.47x2.62	1
11	1382050	Bolt	5/16" 24 UNF 1"	4 T221"
12	1980290	Sight glass	3/8" G	2
13	620340	Bolt	M10x20	3 T217*
14	200231	Washer		6
15	2960080	Pin		1
16	2960030	Gear	Z=85	1
17	881090	Key		1
18	600180	O-ring	Ø 7.66x1.78	1
19	2960040	Pinion	Z=14 (3/4")	1
20	160671	Bolt	M10x25	4 T221"
21	1220260	Bearing		1
22	2960010	Cover		1
23	650270	Gasket		1
24	620561	O-ring	Ø 78x2.5	1 a
25	160670	Bolt	M10x25	3 T217*



Suggested Oil

Type

90 W Gear Lube

For gas engine with 3/4" P.T.O. shaft, flange SAE J609a

*Torque: in-lbs +/- 10%